MCS

MCS221N−2017
MCS221N−2019

PC



Terminal numbers are not shown on the switch.

Part No. \ Switching function	Position (A)	Position (B)
MCS222N−2016 Silver plated	ON	ON
MCS221N−2017 Silver plated		
MCS222N−2018 Gold plated		
MCS221N−2019 Gold plated		
Connecting terminals	C1−1 C2−3	C1−2 C2−4
Circuit diagram		

MCS222N−2016
MCS222N−2018

R/A



Terminal numbers are not shown on the switch.

■PC Hole Layouts



MCS421N−2031
MCS421N−2033

PC



Terminal numbers are not shown on the switch.

Part No. \ Switching function	Position (A)	Position (B)
MCS422N−2030 Silver plated	ON	ON
MCS421N−2031 Silver plated		
MCS422N−2032 Gold plated		
MCS421N−2033 Gold plated		
Connecting terminals	C1−1 C2−3 C3−5 C4−7	C1−2 C2−4 C3−6 C4−8
Circuit diagram		

MCS422N−2030
MCS422N−2032

R/A



Terminal numbers are not shown on the switch.

■PC Hole Layouts